

Instructions for use of the WABCO self-leveling system

The WABCO self-leveling system automates and facilitates the operation of air suspension.

Description

For system with 2 axles:

- The system is operated using a wireless remote control and handbrake lever. Lifting of handbrake is required for loading. Then, after loading, lower the handbrake lever to the down position. At this point, the system automatically raises the suspension to a pre-set level that is intended for driving. The system can also be operated manually using the buttons: 1 (lowering) and 2 (lifting). Buttons 3 and 4 (FN) are not used to operate the suspension.

For PPP system:

- The system is only operated with a wireless remote control. Pressing the button 3 or 4 (FN) once depending on the version puts the vehicle in driving mode with a trailer, maintaining a maximum load of 750 kg or with a raised trailer. In each of the modes it is also possible to manually via control buttons 3 and 4 (FN).

Wireless remote control

